

Bioengineering 280A
Principles of Biomedical Imaging

Fall Quarter 2006
MRI Lecture 6

Thomas Liu, BE280A, UCSD, Fall 2006


Moving Spins

So far we have assumed that the spins are not moving (aside from thermal motion giving rise to relaxation), and contrast has been based upon T_1 , T_2 , and proton density. We were able to achieve different contrasts by adjusting the appropriate pulse sequence parameters.

Biological samples are filled with moving spins, and we can also use MRI to image the movement. Examples: blood flow, diffusion of water in the white matter tracts. In addition, we can also sometimes induce motion into the object to image its mechanical properties, e.g. imaging of stress and strain with MR elastography.

Thomas Liu, BE280A, UCSD, Fall 2006

Phase of Moving Spin



Thomas Liu, BE280A, UCSD, Fall 2006

Phase of a Moving Spin

$$\begin{aligned}
 \varphi(t) &= -\int_0^t \Delta\omega(\tau) d\tau \\
 &= -\int_0^t \gamma \Delta B(\tau) d\tau \\
 &= -\int_0^t \gamma \vec{G}(\tau) \cdot \vec{r}(\tau) d\tau \\
 &= -\gamma \int_0^t [G_x(\tau)x(\tau) + G_y(\tau)y(\tau) + G_z(\tau)z(\tau)] d\tau
 \end{aligned}$$

Thomas Liu, BE280A, UCSD, Fall 2006

Phase of Moving Spin

Consider motion along the x-axis

$$x(t) = x_0 + vt + \frac{1}{2}at^2$$

$$\begin{aligned}\varphi(t) &= -\gamma \int_0^t G_x(\tau)x(\tau)d\tau \\ &= -\gamma \int_0^t G_x(\tau) \left[x_0 + v\tau + \frac{1}{2}a\tau^2 \right] d\tau \\ &= -\gamma \left[x_0 \int_0^t G_x(\tau)d\tau + v \int_0^t G_x(\tau)\tau d\tau + \frac{a}{2} \int_0^t G_x(\tau)\tau^2 d\tau \right] \\ &= -\gamma \left[x_0 M_0 + vM_1 + \frac{a}{2} M_2 \right]\end{aligned}$$

Thomas Liu, BE280A, UCSD, Fall 2006

Phase of Moving Spin

$$\varphi(t) = -\gamma \left[x_0 M_0 + vM_1 + \frac{a}{2} M_2 \right]$$


$$M_0 = \int_0^t G_x(\tau)d\tau \quad \text{Zeroth order moment}$$

$$M_1 = \int_0^t G_x(\tau)\tau d\tau \quad \text{First order moment}$$

$$M_2 = \int_0^t G_x(\tau)\tau^2 d\tau \quad \text{Second order moment}$$

Thomas Liu, BE280A, UCSD, Fall 2006

Flow Moment Example



$$M_0 = \int_0^t G_x(\tau) d\tau = 0$$

$$M_1 = \int_0^t G_x(\tau) \tau d\tau$$


$$= -\int_0^T G_0 \tau d\tau + \int_T^{2T} G_0 \tau d\tau$$

$$= G_0 \left[-\frac{\tau^2}{2} \Big|_0^T + \frac{\tau^2}{2} \Big|_T^{2T} \right]$$


$$= G_0 \left[-\frac{T^2}{2} + \frac{4T^2}{2} - \frac{T^2}{2} \right] = G_0 T^2$$

Thomas Liu, BE280A, UCSD, Fall 2006

Phase Contrast Angiography (PCA)



$$\varphi_1 = -\gamma v_x M_1 = \gamma v_x G_0 T^2$$



$$\varphi_2 = -\gamma v_x M_1 = -\gamma v_x G_0 T^2$$


$$\Delta\varphi = \varphi_1 - \varphi_2 = 2\gamma v_x G_0 T^2$$

$$v_x = \frac{\Delta\varphi}{2G_0 T^2}$$

Thomas Liu, BE280A, UCSD, Fall 2006

PCA example

$-G_0$



White =
Flow direction AP (↓)

White =
Flow direction RL (→)

Thomas Liu, BE280A, UCSD, Fall 2006


http://www.medical.philips.com/main/products/mri/assets/images/case_of_week/cotw_51_s5.jpg

Aliasing in PCA

Define VENC as the velocity at which the phase is 180 degrees.


$$VENC \equiv \frac{\pi}{\gamma G_0 T^2}$$

Because of phase wrapping the velocity of spins flowing faster than VENC is ambiguous.



Thomas Liu, BE280A, UCSD, Fall 2006

Aliasing Solutions



Use multiple VENC values so that the phase differences are smaller than π radians.

$$\varphi_1 = \pi \frac{v_x}{VENC_1}$$

$$\varphi_2 = \pi \frac{v_x}{VENC_2}$$

$$\varphi_1 - \varphi_2 = \pi v_x \left(\frac{1}{VENC_1} - \frac{1}{VENC_2} \right)$$

Thomas Liu, BE280A, UCSD, Fall 2006

Velocity k-space

A bipolar gradient introduces a phase modulation across velocities of the form $\gamma v_x G_0 T^2$

We can make measurements with different amounts of phase modulation and then integrate over velocities to obtain

$$\begin{aligned} M(k_{v_x}) &= \int_{-\infty}^{\infty} m(v_x) e^{j\varphi(v_x)} dv_x \\ &= \int_{-\infty}^{\infty} m(v_x) e^{-j\gamma v_x G_0 T^2} dv_x \\ &= \int_{-\infty}^{\infty} m(v_x) e^{-j2\pi k_{v_x} v_x} dv_x \\ &= F[m(v_x)] \quad \text{with } k_{v_x} = \frac{\gamma}{2\pi} G_0 T^2 \end{aligned}$$

By making measurements with bipolar gradients of varying amplitudes/durations and taking the inverse transform of the measurements, we can obtain the velocity

distribution.

Thomas Liu, BE280A, UCSD, Fall 2006


Velocity k-space

$$M(k_x, k_{v_x}) = \int_{-\infty}^{\infty} \int_{-\infty}^{\infty} m(x, v_x) e^{-j2\pi k_x x} e^{-j2\pi k_{v_x} v_x} dx dv_x$$

In addition, we can apply imaging gradients so that we can eventually obtain the velocity distribution at each point in space. A full k-space acquisition would then yield 6 dimensions -- 3 spatial dimensions and 3 velocity dimensions.

Thomas Liu, BE280A, UCSD, Fall 2006

Readout Gradient Flow Artifacts




During readout moving spins within the object will accumulate phase that is in addition to the phase used for imaging. This leads to

- 1) Net phase at echo time TE = 2T.
- 2) An apparent shift in position of the object.
- 3) Blurring of the object due to a quadratic phase term.

Thomas Liu, BE280A, UCSD, Fall 2006


Flow Artifacts

Plug Flow



All moving spins in the voxel experience the same phase shift at echo time.

Laminar Flow




Spins have different phase shifts at echo time. The dephasing causes the cancellation and signal dropout.

Thomas Liu, BE280A, UCSD, Fall 2006

Flow Compensation


Readout Gradient



At TE both the first and second order moments are zero, so both stationary and moving spins have zero net phase.


Thomas Liu, BE280A, UCSD, Fall 2006

Inflow Effect



Thomas Liu, BE280A, UCSD, Fall 2006

Time of Flight Angiography



Thomas Liu, BE280A, UCSD, Fall 2006

Cerebral Blood Flow (CBF)

CBF = Perfusion

= Rate of delivery of arterial blood to a capillary bed in tissue.

Units: $\frac{\text{(ml of Blood)}}{\text{(100 grams of tissue)(minute)}}$

Typical value is 60 ml/(100g-min) or
60 ml/(100 ml-min) = 0.01 s^{-1} , assuming
average density of brain equals 1 gm/ml

Thomas Liu, BE280A, UCSD, Fall 2006





Fig. 2.2

Buxton 2002

Thomas Liu, BE280A, UCSD, Fall 2006




Arterial Spin Labeling

- Magnetically tag inflowing arterial blood
- Wait for tagged blood to flow into imaging slice
- Acquire image of tissue + **tagged blood**
- Apply control pulse that doesn't tag blood
- Acquire control image of tissue
- Control image - tag image = **blood image**

Thomas Liu, BE280A, UCSD, Fall 2006

Arterial Spin Labeling (ASL)




Thomas Liu, BE280A, UCSD, Fall 2006

Credit: Wen-Ming Luh

Arterial Spin Labeling (ASL)


- water protons as freely diffusible tracers



Thomas Liu, BE280A, UCSD, Fall 2006

Courtesy of Wen-Ming Luh


Multislice CASL and PICORE



Thomas Liu, BE280A, UCSD, Fall 2006


Credit: E. Wong

Diffusion



$$\langle \Delta x^2 \rangle = Nd^2 = 2DT$$

D = diffusivity




In brain:
D \approx 0.001 mm²/s
For T=100 msec,
 $\Delta x \approx 15 \mu$

Thomas Liu, BE280A, UCSD, Fall 2006

Credit: Larry Frank

Diffusion Weighting



Assume $\delta \ll T$

$$\varphi(t_1) \approx -\gamma G_0 x(t_1) \delta$$

$$\varphi(t_2) \approx +\gamma G_0 x(t_2) \delta$$

Net Phase T

$$\varphi \approx \varphi(t_1) + \varphi(t_2) = \gamma G_0 [x(t_2) - x(t_1)] \delta = \gamma G_0 \Delta x \delta$$

Average Squared Phase

$$\langle \varphi^2 \rangle = \gamma^2 G_0^2 \delta^2 \langle (\Delta x)^2 \rangle = \gamma^2 G_0^2 \delta^2 2DT$$

Signal

$$S \propto e^{-\langle \varphi^2 \rangle / 2} = e^{-\gamma^2 G_0^2 \delta^2 DT} = e^{-bD} \text{ where } b = \gamma^2 G_0^2 \delta^2 T$$

A more careful analysis yields $b = \gamma^2 G_0^2 \delta^2 (T - \delta/3)$

b-factor


Thomas Liu, BE280A, UCSD, Fall 2006

Diffusion Weighted Images

T2 weighted

Diffusion Weighted

Angiogram





After a stroke, normal water movement is restricted in the region of damage. Diffusivity decreases, so the signal intensity increases.

Thomas Liu, BE280A, UCSD, Fall 2006

<http://lehighmri.com/cases/dwi/patient-b.html>

Restricted Diffusion

D depends on direction





Diffusion tensor:
3 values of D
3 angles

Thomas Liu, BE280A, UCSD, Fall 2006


Credit: Larry Frank

Diffusion Imaging Example



Thomas Liu, BE280A, UCSD, Fall 2006


Q-ball imaging



Thomas Liu, BE280A, UCSD, Fall 2006

Tuch et al, Neuron 2003

Fiber Tract Mapping




Mori et al., MRM 2002

Thomas Liu, BE280A, UCSD, Fall 2006

fMRI

MRI studies brain anatomy.




Functional MRI (fMRI) studies brain function.



Thomas Liu, BE280A, UCSD, Fall 2006

http://defiant.ssc.uwo.ca/Jody_web/fmri4dummies.htm

fMRI Setup




Thomas Liu, BE280A, UCSD, Fall 2006

http://defiant.ssc.uwo.ca/Jody_web/fmri4dummies.htm

fMRI Acquisition

High spatial resolution

High temporal resolution



MP-RAGE

Voxel volume: 1 mm³
Imaging time: 6 min


EPI

Voxel volume: 45 mm³
Imaging time: 60 msec

Thomas Liu, BE280A, UCSD, Fall 2006



Buxton 2002

Visual Activation



Flickering Checkerboard

OFF (60 s) - ON (60 s) - OFF (60 s) - ON (60 s) - OFF (60 s)




Source: Kwong et al., 1992

Thomas Liu, BE280A, UCSD, Fall 2006


http://defiant.ssc.uwo.ca/Jody_web/fmri4dummies.htm

Finger Tapping Task



Thomas Liu, BE280A, UCSD, Fall 2006

Hemoglobin



Oxygen binds to the iron atoms to form oxyhemoglobin HbO_2

Release of O_2 to tissue results in deoxyhemoglobin dHbO_2

Thomas Liu, BE280A, UCSD, Fall 2006

<http://www.people.virginia.edu/~rjh9u/hemoglob.html>


Effect of dHBO₂

dHBO₂ is paramagnetic due to the iron atoms. As it becomes oxygenated, it becomes less paramagnetic.

dHBO₂ perturbs the local magnetic fields. As blood becomes more deoxygenated, the amount of perturbation increases and there is more dephasing of the spins. Thus as dHBO₂ increases we find that T_2^* decreases and the amplitude $\exp(-TE/T_2^*)$ image of a T_2^* weighted image will decrease. Conversely as dHBO₂ decreases, T_2^* increases and we expect the signal amplitude to go up.

Thomas Liu, BE280A, UCSD, Fall 2006

Field Distortions Around a Magnetized Blood Vessel
Fig. 16.2





Thomas Liu, BE280A, UCSD, Fall 2006

Buxton 2002

BOLD Effect

Blood Oxygen Level Dependent signal

\uparrow neural activity \rightarrow \uparrow blood flow \rightarrow \uparrow oxyhemoglobin \rightarrow \uparrow T2* \rightarrow \uparrow MR signal




Source: [fMRIB Brief Introduction to fMRI](#)

Source: Jorge Jovicich

Thomas Liu, BE280A, UCSD, Fall 2006

http://defiant.ssc.uwo.ca/Jody_web/fmri4dummies.htm


BOLD Dynamics



Thomas Liu, BE280A, UCSD, Fall 2006

Credit: Rick Buxton


Fig. 17.5 **BOLD Dynamics**
Rat Forepaw Stimulation
(Mandeville, et al, 1999)



Thomas Liu, BE280A, UCSD, Fall 2006

Buxton 2002

BOLD and Vascular Dynamics



Thomas Liu, BE280A, UCSD, Fall 2006


Timeline

Michael Crichton, 1999



“Most people”, Gordon said, “don’t realize that the ordinary hospital MRI works by changing the quantum state of atoms in your body ... But the ordinary MRI does this with a very powerful magnetic field - say 1.5 tesla, about twenty-five thousand times as strong as the earth’s magnetic field. We don’t need that. We use Superconducting QUantum Interference Devices, or SQUIDS, that are so sensitive they can measure resonance just from the earth’s magnetic field. We don’t have any magnets in there”.


Thomas Liu, BE280A, UCSD, Fall 2006

J. Clarke, UC Berkeley



Thomas Liu, BE280A, UCSD, Fall 2006





Seeley et al, JMR 2004

Thomas Liu, BE280A, UCSD, Fall 2006